Twin Light Blaster

Simple Assembly Instructions - **Please keep for future reference**



Components

Ⓐ 1 x Main Light Blaster



Ⓑ 1 x Light Blaster

View On Front Of Main Light Blaster



Ⓒ 1 x Battery box



Fittings

Ⓐ 1 x Scart Converter



IMPORTANT

1. *Read these instructions carefully and familiarise yourself with the procedure before assembling the unit.*

5-04

Assembly Instructions

Stage 1 – Important Safety Instructions

"Read all instruction before use" and save for future reference.

- **This product is not suitable for children under 5 years old.**
- **Do not repair or remove any parts from the unit as this will cause a hazard.**
- **Do not store the unit in temperatures below 5 degrees ˚C or above 40 degrees ˚C.**
- **Do not expose the unit to direct sunlight.**

Note On Batteries:

- **Do not mix different types of batteries or an old battery with a new one.**
- **To prevent the risk of leakage or explosions, never recharge the batteries, apply heat or take them apart.**
- **When not using batteries, remove them to prevent battery drain.**
- **If liquid leaks from the batteries, throw them away. Thoroughly clean the battery compartment with a dry cloth.**

Troubleshooting :

- **When the pictures on TV screen become blurry, unclear or vibrating, the batteries are probably exhausted. Please change batteries.**
- **When there is no picture on TV screen or there is only sound, the AV plugs to TV might be connected incorrectly.**
- **Children are advised not to play this game set continuously for more than 2 hours. Prolonged concentration on TV screens may affect the health of the children and may cause harm to their eyes.**

Assembly Instructions

Stage 2 – Installing the Batteries

NOTE: Before use your must read the safety warning instructions.

1. Press the Release Button Ⓚ to release the Battery Box Ⓒ from the Main Light Blaster Ⓐ unit. **See fig. 1.**



fig. 1

2. Open the cover of the Battery Box Ⓒ and insert 4 "AAA" (R03) 1.5V batteries (not included) according to the engraved polarity (+, -) signs on the battery compartment. **See fig. 2.**



fig. 2

3. Replace the Battery Box Ⓒ cover. **See fig. 3.**



fig. 3

4. Locate the Battery Box Ⓒ back into the bottom of the main Light Blaster Ⓐ unit. **See fig. 4.**



fig. 4

Assembly Instructions

Stage 3 – Connection the to a T.V.

Two Player Mode

1. Connect the Light Blaster Ⓑ to the Main Light Blaster Ⓐ for two player games. The jack for the second player is located on the handle of the Main Light Blaster Ⓐ.
   See fig. 5.

Connection to a T.V.
The unit can be connected to a T.V. via the scart inlet or the T.V. R.C.A. sockets. Ensure your T.V. is switched off during connection.

Connection to the RCA outlet

1. Plug the 3 way cable (RCA) into the three sockets on the front or rear of your T.V. Ensure you connect the colour coded cable to the corresponding colours on the socket.
   See fig. 6.
2. When you turn on your T.V. set to the A.V. (Video) channel.

Connection to the Scart outlet

1. Plug the Scart Converter Ⓐ into the scart socket on the back of your T.V. Ensure you align the pins correctly. Then plug the 3 way colour coded cable to the corresponding socket on the Scart converter.
   See fig. 7.
2. When you turn on your T.V. set to the A.V. (Video) channel.



fig. 5


fig. 6



fig. 7


fig. 8


Illustration Shows Two Player Mode

Assembly Instructions

Stage 4 – Operation

To Begin Play

1. Turn on the Main Light Blaster Ⓐ by switching the ON/OFF Button Ⓙ to the ON position. The main menu will appear on the T.V. screen.
   See fig. 9.
2. Use the Up and Down Arrows Ⓓ to scroll through the menu to make the game selection required. Press the Start Button Ⓘ to select.
   See fig. 10.
3. Press the Reset Ⓔ button at any time to return to the main menu.
   See fig. 10.
4. Use the Arrow Keys Ⓓ, Action Keys Ⓗ or joystick Ⓕ for directional control during use. For shooting games aim the Light Blaster at the TV screen and shoot by pressing the trigger.
   See fig. 10.



fig. 9
View On Front Of Main Light Blaster



fig. 10

Assembly Instructions

Stage 5 – Game List

Fun Click:	The Screen shows various items like apple, worm...etc. All you have to do is to eliminate all the items on the screen. You can eliminate the items when 2 or more of the same items are next to each other.
Box World:	Think twice before you move. Move all the boxes to the red dots and you win.
Diamond:	Move the bar left and right to hit the bouncing ball to destroy all the diamonds.
Strength Pop Pop:	Pop Pop marbles are falling down the waterfall. You have to turn the falling marbles around, move it left and right to fit it in space. The marbles will disappear when it forms a straight line across the wall of the waterfall.
Matching:	Flip the cards over and match the graphics.
Soccer:	Two player game. Control your chosen football team to defend, pass and score a goal.
Panda:	Panda is in adventure! Help it to pass all the stages.
Future Tank:	2 players game. You have to protect the headquarters. Drive your tanks to destroy the enemies.
Forest Guard:	Shooting game. Aim the Light Blaster at the screen and shoot the bad guy holding the weapon.
Cowboy:	Duel with a cowboy. Aim the Light Blaster at the screen and be the quickest to shoot during the duel.
Space 2050:	Aliens are attacking! Are you ready to shoot them down? Aim the Light Blaster at the screen and fire at the UFO's.
UFO Race:	Move your spaceship on the track to win the race.
Space Invader:	Protect the earth with your spaceship. Destroy all the attacking UFO invaders.
Tennis:	2 player game. A sport game for you and your partner. Double play mode is available.

Assembly Instructions

Stage 5 – Game List

Mars:	Move your spaceship outside Mars and destroy the UFO's.
Baseball:	A strategic game which requires some skill. Hit the baseball and score a home run.
Tunny:	2 player game. Tunny the helicopter is ready to defend and destroy the enemy.
Super Elf:	2 player game. It is an adventure game. Jump and escape all the obstacles toward the goals.
Aether Tiger:	Aether Tiger is a space protecting aircraft. Protect space by destroying the advancing enemy's.
Boat Race:	Drive your boat with the joystick to win the race.

Care and Maintenance

- **Keep the main Lightblaster and second joypad clean by wiping it with a slightly damp cloth.**
- **Keep the main and second Lightblaster joypad and all the accessories away from direct sunlight, UV light, direct sources of heat, moisture and water.**
- **Remove batteries when the game set will not be used for an extended period of time.**
- **Do not drop the unit on hard surfaces.**
- **Do not attempt to dismantle the unit if a fault occurs.**
- **Not suitable for children under the target age due to small parts.**
- **Remove or dispose of all packaging (including polybags) safely before giving to children.**
- **Please keep this User's Manual for future reference.**